



Product: Can-Am Defender Tail Lights

Disclaimer: For safety please unhook the battery terminals and keep the key in the off position at all times until the lights are ready to be tested

Instructions:

- Lift the rear box to the tilt position
- Remove the lower screws from the box side panels



- Remove the side screws from the box side panel



Thank you for your purchase.

For a list of more products we offer please visit marqcadeng.com or message us on facebook at marqCAD Engineering if you don't see what you are looking for on the website.

- Remove the stock tail lights by removing the tail light harness connector and then the 2 bolts on the inside of the bed where the tail gate folds up. Bolts will use a 10mm socket. Lift up on the top part of the connector to remove the plug.



- Remove the two metal clips from the OEM tail lights by lifting up on the inside of the clip and sliding it off. Make sure the clip inner looks like the picture below so it latches to the new light correctly.



- Slide the clips on the correct side of the new tail light and install the light in the reverse order of removing the OEM tail light.
- Test the tail light and then replace the side panels in the reverse order of removal.

Thank you for your purchase.

For a list of more products we offer please visit marqcadeng.com or message us on facebook at marqCAD Engineering if you don't see what you are looking for on the website.