



Product: Can-Am Defender Digital Mirror Mount

Disclaimer: N/A

Instructions:

• Remove the 2 lower screws from the front headliner panel. In some cases these two bolts will be holding the rear view mirror on as well.



• Hold the new mount in place and install the screws through the mount and into the original holes in the plastic headliner.



• Install Mirror around the mount same as they would on the rearview mirror.

Thank you for your purchase.

For a list of more products we offer please visit marqcadeng.com or message us on facebook at marqCAD Engineering if you don't see what you are looking for on the website.