



Product: Can-Am Defender Trailer Light 4 Pin – With Blinkers

Disclaimer: For safety please unhook the battery terminals and keep the key in the off position at all times until the lights are ready to be tested

Instructions:

- Lift the rear box to the tilt position
- Remove the lower screws from the box side panels both passenger and driver.



- Remove the side screws from the box side panel Both passenger and driver side.



Thank you for your purchase.

For a list of more products we offer please visit marqcadeng.com or message us on facebook at marqCAD Engineering if you don't see what you are looking for on the website.

- Remove the tail light harness connector, Lift up on the top part of the connector to remove the plug. Then plug our harness in line with the tail light harness and tail light. Harness will be labeled driver and passenger side.



- Once plugged in test the tail light and blinker functions to insure the lights all work properly. Then run the harness along the stock wiring to the center of the box, secure with zip ties, and re-install the side panels. Using the supplied mount, mount the 4 pin switch in your desired location.

Thank you for your purchase.

For a list of more products we offer please visit marqcadeng.com or message us on facebook at marqCAD Engineering if you don't see what you are looking for on the website.