



Product: Can-Am Defender Trailer Harness

Disclaimer: Disconnect the battery when installing any electrical components

Instructions:

- Locate the tail light harness plug along the passenger side of the frame under the tilt bed near the voltage regulator. Connect the MCE harness to each end of the OEM plugs.



- Run the light harness along the OEM tail light harness to the rear of the machine by the bed bracket and run the split to the proper side of the machine. Connect the bullet connectors to the lights. Attach the light harness to the OEM wiring using the supplied zip ties. In the location by the exhaust wrap the wires with the supplied heat tape.
- Mount the 4 pin holder bracket in your desired location using the supplied hardware and push the plug into the mount.

Thank you for your purchase.

For a list of more products we offer please visit marqcadeng.com or message us on facebook at marqCAD Engineering if you don't see what you are looking for on the website.