



Product: Renegade Snorkel Horn Cover

Disclaimer: This product is not intended to keep **100%** of water and debris out of your snorkels. This product is intended to not get clogged with dirt and debris as the stock screen cover does, limiting air flow.

Instructions:

NOTE: Snorkel Insert comes with fine mesh installed but in some applications this will clog to easy and will need to be swapped out with the provided larger mesh material.

Filter is sold separately from the snorkel cover.

- Remove the stock snorkel horn mesh screen.
- If didn't order the Intake Insert Screen you can skip down to the cover installation on the next page. If you would like to order this insert please visit <https://marqcadeng.com/shop-mce-offroad>
- Push the top of the insert into the top of the intake at an angle as shown below. Note: This can be installed without removing the snorkel horn.



- While pushing up on the insert push the bottom of the insert into the bottom of the snorkel intake. Only press along the outsides of the insert, pressing on the screen/mesh may cause the mesh to break.



Thank you for your purchase.

For a list of more products we offer please visit marqcadeng.com or message us on facebook at marqCAD Engineering if you don't see what you are looking for on the website.

- Slide the horn cover into place making sure that the edges mount as flush as possible. Line up the tabs at the bottom of the horn and the holes at the top of the snorkel horn line up with the mounting holes in the horn cover.



- Install the supplied screws and washers as seen in the picture below. Do not overtighten these as it will cause the part to break in most cases.



Thank you for your purchase.

For a list of more products we offer please visit marqcadeng.com or message us on facebook at marqCAD Engineering if you don't see what you are looking for on the website.