



Product: Can-Am X3 Reverse Lights/Housings

Disclaimer: When wiring it is suggested to disconnect the battery terminals

Instructions:

- Drill a hole $\frac{3}{8}$ " to $\frac{1}{2}$ " in the location shown below, right above the corner in the housing. This will be where the wires will run through to the backside of the tail light housing.



Thank you for your purchase.

For a list of more products we offer please visit marqcadeng.com or message us on facebook at marqCAD Engineering if you don't see what you are looking for on the website.

- With light pressure hold the housing in place and secure using the supplied screws. Each housing will have two screws. Do not over tighten the screws as you may strip out the OEM Tail light housing or crack the reverse light housing.



Thank you for your purchase.

For a list of more products we offer please visit marqcadeng.com or message us on facebook at marqCAD Engineering if you don't see what you are looking for on the website.